

# Bellows-Sealed Valves

## Maintenance Kits

### Bellows Kits



**BG, BK, BKT, BMG, BMRG, BRG, UG, and UK Series**

**Manual Valves and Valves with 5, 6, and 8 Series Pneumatic Actuators**

Kits include welded subassembly (stem, bellows, and weld ring), pin(s), and instructions.

Valve Series	Kit Ordering Number	
	Stainless Steel and Brass Valves	Alloy 400 Valves
4BG, 4BK, 4BKT	SS-4BK-K1	M-4B-K1
BMG	SS-4BM-K1	M-4BM-K1
BMRG	SS-4BMR-K1	M-4BMR-K1
4BRG, 6BK, 8BK, 6BG, 8BG	SS-8B-K1	M-8B-K1
4UG, 4UK, 6UG, 6UK, 8UG, 8UK	SS-4U-K1	—
12UG, 12UK	SS-12U-K1	—

### BK Series with 1 Series Pneumatic Actuators



Kits include welded subassembly (stem, bellows, weld ring), piston and stem O-rings, lock nut, washer, and instructions. The ordering number specifies stainless steel (**SS**) for stainless steel and brass valves. For alloy 400 valve kits, replace **SS** with **M**.

Example: **M-4BA-K1**

Valve Series	Kit Ordering Number
4BK, 6BK, 8BK	SS-4BA-K1

### Stem Tip/Adapter Kits



Kits include stem tip/adapter subassembly and instructions. Ordering numbers specify stainless steel (**SS**) for stainless steel and brass valves. For alloy 400 valve kits, replace **SS** with **M**.

Example: **M-4BR-K5**

### BG, BM, BMRG, BRG, UG, and UK Series

Valve Series	Kit Ordering Number
4BG, 4UG	SS-4B-ST-K5 <sup>①</sup>
BMRG, 4BRG, 4URG	SS-4BR-K5
4UK	SS-4BA-K5
6UK, 8UK	SS-8BA-K5
6BG, 6UG, 8BG, 8UG	SS-8B-K5
12UG	SS-12U-ST-K5
12UK	SS-12UK-K5

<sup>①</sup> For alloy 400 valves, replace **SS** with **M** and **ST** with **M5**.

Example: **M-4B-M5-K5**

### BK and BKT Series

Valve Series	Kit Ordering Number	
	Manual Valves and Valves with 5 Series Pneumatic Actuators	Valves with 1 Series Pneumatic Actuators
4BK	SS-4BA-K5	SS-4BK-K5
4BKT	SS-4BK-K5	—
6BK, 8BK	SS-8BA-K5	SS-8BK-K5

### Manual BN Series

Valve Series	Kit Ordering Number
BN4	KF-BN4-K5
BN8	KF-BN8-K5



## Bellows/Stem/Stem Tip/ Adapter Kits

### BN, HB, and HK Series

Kits include bellows/stem tip/adaptor subassembly, and gasket<sup>①</sup> of the original materials specified in the product catalog and instructions.

① Not included for HG and HK series; not required for BN series.

Valve Series	Kit Ordering Number	
	Manual Valves	Pneumatically Actuated Valves
BN4	SS-BN4-KF-K6	SS-BN4-K1
BN8	SS-BN8-KF-K6	SS-BN8-K1
HB	—	SS-HB-KF-K5
HK	B-4HK-KA	
HK with copper stem tip	B-4HG-KA	—



## Gasket Kits

### BG, BK, BKT, BMG, BMRG, BRG, HB, HK, UG, and UK Series

Kits include body-to-bonnet gasket of the original material specified in the product catalog and instructions. Ordering numbers specify stainless steel (**SS**) for stainless steel and brass valves. For alloy 400 valve kits, replace **SS** with **M**.

Example: **M**-4BGO-K5-T

Valve Series	Kit Ordering Number
BG, BRG, BMG, BMRG, 4UG, 6UG, 8UG	SS-4BGO-K5-SV <sup>①</sup>
BK, BKT, 4UK, 6UK, 8UK	SS-4BGO-K5-T
HB	6L-HB-K28
HK	CU-4HG-K12T
HK with copper stem tip	CU-4HG-K12
12UG, 12UK	SS-12UGO-K5-SV

① For brass valves, replace **SV** with **T**.  
Example: **SS**-4BGO-K5-**T**

### Safe Product Selection

When selecting a product, the total system design must be considered to ensure safe, trouble-free performance. Function, material compatibility, adequate ratings, proper installation, operation, and maintenance are the responsibilities of the system designer and user.

**Caution: Do not mix or interchange parts with those of other manufacturers.**

## Warranty Information

Swagelok products are backed by The Swagelok Limited Lifetime Warranty. For a copy, visit [swagelok.com](http://swagelok.com) or contact your authorized Swagelok representative.